



WWW.BCFAB.COM

1975-1979 CONTINENTAL FRONT BRACKETS

1. Raise and support the vehicle to a safe and comfortable working height, with the front suspension hanging freely. Remove your front coil springs, refer to your service manual for disassembly procedure.



2. The coil spring pocket will need to be trimmed for air spring clearance as shown in image.

3. Place the upper cup bracket onto air spring and secure with bolts.

4. Apply Teflon tape to the air fitting, and thread into air spring.

5. Thread allthread into the upper cup bracket. Next install the air spring assembly using supplied hardware.



6. Bolt air spring onto lower mount.

7. Raise the control arm until the lower air spring bracket sits flush. Weld into place.

8. Once the air spring is secured cycle the suspension, and make sure there is at least 1/2" gap around the air spring. Trim material if necessary. **ANY RUBBING WILL RESULT IN AIR SPRING FAILURE** which is a non-warrantable issue.

Brackets are designed for use with Air Lift Dominator D2500, Slam Specialties RE6, Firestone 255c, or equivalent 6" or 2500# airbags.