



Airbag Bracket Instructions 60-72 Chev C10 Rear

1. Raise and support car at a safe, comfortable working height. Let the front suspension hang freely.

2. Remove coil springs and shock absorbers. Refer to factory service manual for proper disassembly procedure.



3. Insert air fitting into air spring using thread sealant.

4. Bolt upper mount onto air spring using 3/8" bolts, with air fitting pointing to cut in bracket.

5. Screw the 1/2" stud into the nut on upper mount.

6. Bolt the assembly onto your frame, with the stud coming through the coil mounting hole. Secure with 1/2" nut and washer.

NOTE: Larger line and fitting may require notching of bracket and frame for clearance.

7. Bolt the bottom of the air spring and lower mounting plate to trailing arm using supplied 3/8" stud, nut and washer.

8. Double check for clearance for air spring through range of travel.