



65-70 Chevrolet Impala Front Brackets



1. Place the lower air spring plate onto the lower control arm as shown in the picture. This is the driver side. The plate will index off the rear strut arm bolt. The other two holes must be drilled for 3/8" bolts.



2. The coil spring pocket will need to be trimmed for air spring clearance as shown in the picture.

3. Apply Teflon tape to air fitting and thread into air spring.

4. Place cup bracket onto air spring and secure with bolts.

5. Thread stud onto cup bracket.

6. Bolt air spring onto lower mount.