



WWW.BCFAB.COM

# 1963-1965 RIVIERA FRONT SHOCK RELOCATION

**1.** Raise and support the vehicle to a safe and comfortable working height, with the front suspension hanging freely.

**2.** The upper shock mounts are to be bolted to the side of the frame (or welded). The lower tab is welded to the side of the TC Rod. (IMG 02)

**3.** Cycle suspension with a jack to check for clearance, double check all mounting hardware, and turn wheels lock to lock, to check clearance against shock.



IMG 01



IMG 02