

1963-1987 CHEVROLET C10 DROP POCKETS

1. Drill out spot-welds on bump-stop bracket.



2. Once bump-stop bracket is removed, clean area thoroughly, as shown.



3. Place the drop pocket cup onto the control arm, and trace around the outside diameter with a scribe or marker.



4. Cut inside of the traced line, and check fitment. If drop pocket cup does not fit remove more material.



1963-1987 CHEVROLET C10 DROP POCKETS

5. Clean area around the cut.



6. Place drop pocket cup into lower control arm and ensure fitment is correct. The top of the drop pocket cup should be level with the control arm.



7. Tac the drop pocket cup into place and then weld around the perimeter as shown.

