



## Mercedes W108 Rear Brackets



1. Remove factory coil springs by unbolting shocks and allowing suspension to droop.

2. Assemble RE6 Air Spring to brackets as shown.

3. Lower mount can be bolted directly through lower suspension arm. Upper mount can simply rest on factory coil perch, or you can drill a hole through to bolt it with the included hardware.

4. You will need to drill a hole in the upper coil spring pocket to route the air line. Remove all burrs and use a rubber grommet.

5. Apply Teflon tape onto air fitting, screw into air spring, and install completed assembly.

